

# **Robotics**

Buzzer / Ultrasonic sensor


School of Computing, Gachon University

Kang, Sangwoo









- Buzzer Piezo Speaker
  - Piezo buzzer is basically a tiny speaker and is an electronic device that can be used to play tones.






## **Basics** [cont'd]

#### Ultrasonic Sensor

- It emits an ultrasound at 40Hz which travels through the air and if there is an object or obstacle on its path, It will bounce back to the module
- Considering the travel time and the speed of the sound you can calculate the distance









### **Basics** [cont'd]

- The HC-SR04 Ultrasonic Module has 4 pins, Ground, VCC, Trig and Echo
  - The **Ground** and the **VCC** pins of the module needs to be connected to the Ground and the 5 volts pins on the Arduino Board respectively and the **trig** and **echo** pins to any
     Digital I/O pin on the Arduino Board
    - Trig (signal output pin → High state)
    - Echo (signal input pin → High state)





#### **Functions**



#### tone()

- o It can play tones from a piezo buzzer or other speaker. A duration of a buzzer can be specified, otherwise the wave continues until a call to noTone(). Only one tone can be generated at a time. If a tone is already playing on a different pin, the call to tone() will have no effect. If the tone is playing on the same pin, the call will set its frequency.
- Syntax
  - tone(pin, frequency)
  - tone(pin, frequency, duration)
- Parameters
  - *pin*: the pin on which to generate the tone
  - *frequency*: the frequency of the tone in hertz
  - duration: the duration of the tone in milliseconds (optional)




- noTone()
  - Stops the generation of a square wave triggered by tone()
  - Has no effect if no tone is being generated.
- Syntax
  - o noTone(pin)
- Parameters
  - o pin: the pin on which to stop generating the tone



```
o example
    void setup() {
    pinMode(9, OUTPUT);
    tone (9, 262);
    delay(500);
    noTone(9);
}
```

C		32,7	65,4	130,8	261,6	523,3	1046,5	2093,0	4186,0
D		36,7	73,4	146,8	293,7	587,3	1174,7	2349,3	
E		41,2	82,4	164,8	329,6	659,3	1318,5	2637,0	
F		43,7	87,3	174,6	349,2	698,5	1396,9	2793,8	
G		49,0	98,0	196,0	392,0	784,0	1568,0	3136,0	
Α	27,5	55,0	110,0	220,0	440,0	880,0	1760,0	3520,0	
В	30,9	61,7	123,5	246,9	493,9	987,8	1975,5	3951,1	






#### pulseln()

- Reading a pulse (either HIGH or LOW) on a pin.
  - It returns the length of the pulse in microseconds or 0 if no complete pulse was received within the timeout.
- Syntax
  - pulseln(pin, value)pulseln(pin, value, timeout)
- Parameters
  - pin: the number of the pin on which you want to read the pulse (int)
  - value: type of pulse to read: either HIGH or LOW (int)
  - timeout (optional): the number of microseconds to wait for the pulse to be completed:
    - Default is one second.





#### delayMicroseconds()

- o Pausing the program for the amount of time (in microseconds) specified as parameter
  - There are a thousand microseconds in a millisecond, and a million microseconds in a second
- Syntax
  - delayMicroseconds(us)
- Parameters
  - us: the number of microseconds to pause (unsigned int)






```
Example
    int outPin = 2;
    int inPin = 3;
    void setup(){
     Serial.begin(9600);
      pinMode(outPin, OUTPUT); // sets the digital pin as output
      pinMode(inPin, INTPUT); // sets the digital pin as input
    void loop(){
     digitalWrite(outPin, HIGH); // sets the pin on
     delayMicroseconds(10); // pauses for 10 microseconds
     digitalWrite(outPin, LOW); // sets the pin off
     int duration = pulseIn(inPin, HIGH)
      Serial.print("duration = ");
     Serial.print(duration);
```






# Lab. 1 – Piezo buzzer (speaker) I

- Play "School bell's ringing Ding Ding Dong"
  - o use arrays
- Circuit diagram:









## Lab. 2 - Piezo buzzer (speaker) II

- Make a sound when the pushbutton is pressed.
  - $\circ$  e.g. first pushbutton  $\rightarrow$  C(do), second pushbutton  $\rightarrow$  D(re), ...
- Circuit diagram:





## Lab. 3 - Ultrasonic sensor + Piezo buzzer

- Play the notes (more than 3) depends on a distances.
  - o centimeter = duration / 58

